


How to upgrade your DVR-1600V or DVR-800AV

1. Download the files [DVR-1600AV upgrade \(16 Channels\)](#) or [DVR-800AV upgrade \(8 Channels\)](#) depending of the model of your DVR.
 2. The files have been compacted using WinZip; they can be extracted using the standard **Windows XP or Windows Vista WinZip (This program is already included in your Windows Computer and you don't need any extra software to extract the files)** in case that you don't have WinRar installed in your computer.
 3. After download the files you will need to extract the files and copy the files in the head directory of your USB Flash Drive **(The files must be in the head directory of your USB Flash Drive and *NOT* inside a folder in your USB Flash Drive).**
 4. With the files copy correctly inside your USB Flash Drive connect your USB Flash Drive in the front or back USB Port of your DVR.
-


Upgrade Process in your DVR

The next Picture will show you what buttons in your Manual Remote Controller you will be using during the Upgrade Process to move in the menu of the DVR:



1. After the USB Flash Drive has been connected in one of the USP Ports of your DVR a little window will pop up letting you know that the USB Drive has been connected just press the **OK** in your screen using your **ENTER** button in your **Manual Remote Control**.

2. Now Scroll Down in the menu until you find the **SYSTEM INFO** using the buttons **DOWN** in your **Manual Remote Controller** as is shows in the nest picture:



3. Now press the **R** button in your **Manual Remote Controller** to jump to the list. Move to the **UPGRADE** option in the list using your **DOWN** button (The **UPGRADE** option will change the color from white to yellow):

